CRAFTSMAN

610-24147

12.5 cu ft POLY SWIVEL DUMP CART

Patent US8496298

READ AND FOLLOW ALL SAFETY RULES AND OPERATING INSTRUCTIONS BEFORE USING THIS EQUIPMENT

Sears Brands Management Corporation, Hoffman Estates, IL 60194 U.S.A

Assembled in the U.S.A. of domestic and imported components

6002638 - REV B 11/13

Safety Rules

This is the safety alert symbol. It is used to alert you to potential personal injury hazards. Obey all safety messages that follow this symbol to avoid possible injury or death.

Read and understand all safety rules and operating instructions before using this tractor attachment.

Follow all safety rules and operating instructions provided by your vehicle's manufacturer when using attachment.

Never allow children or untrained persons to operate vehicle or attachment.

Do not exceed the vehicle manufacturer's towed weight limit.

Reduce vehicle speed and allow extra stopping distance when towing heavy loads.

Reduce vehicle speed and towed weight when operating on slopes.

Operate up and down slopes, never across the face of slopes.

Do not carry passengers on vehicle or attachment.

Avoid sudden turns or maneuvers.

Do not tow attachment on public roadways.

Do not remove warning decals from product.

Check product for worn, loose, or damaged parts before each use. If any damage is present, repair the product before using.

Check product for loose or missing fasteners before each use. Tighten or replace fasteners as needed before using.

Do not exceed vehicle speed of 6 miles per hour when towing Dump Cart.

Do not exceed Dump Cart rated weight capacity of 1000 pounds.

Carton Contents



1 (x1)



2 (x1)



3 (x1)



19 (x1)



20 (x1)



21 (x1)



22 (x2)



27 (x1)



23 (x4)



26 (x12)



24 (x2)



28 (x2)



25 (x12)

TOOLS REQUIRED FOR ASSEMBLY:

- 1/2" Wrench or Socket
- Grease Gun

Assembly Instructions

1 Attach Undercarriage to Poly Body and tighten hardware.



2 Attach Front Support to Poly Body and tighten hardware.



3 Insert Axle into Undercarriage halfway as shown. Center Spacer inside Swivel Clevis and align with Axle.



Assembly Instructions

4 Slide Axle completely through Undercarriage; Swivel Clevis and Spacer must be captured by Axle.
Align Drawbar with Front Support and press down to latch.



5 Slide Washers, Spacers and Wheels onto Axle and secure with Hairpins as shown.



6 Slide Spring Loaded Hitch Bracket through drawbar and secure with hardware.



Installed



Operating Instructions

Before Using Dump Cart:

1. Apply grease to wheels using grease gun until grease can be seen squeezing out from both sides of the wheel.
2. Check tire pressure and inflate to 28 psi if needed.
3. Read all Safety Rules found on page 1.

How to Use Dump Cart:

1. Attach Dump Cart to your tractor using the supplied hitch pin.
2. Do not exceed 1000 pounds when loading material into the cart body.
3. Distribute the weight of the load as evenly as possible in the cart body for best handling.
4. When hauling heavy loads, verify that your vehicle has adequate towing and braking capacity.
5. Do not exceed 6 miles per hour when towing Dump Cart.

How to Empty Dump Cart:

1. Step down the foot pedal to release the latch mechanism.
2. Lift the body and swivel as desired to guide the material to preferred location.
3. Lift the body entirely and empty material.
4. Lower the body and guide the latch into the drawbar and relatch.

Periodic Maintenance:

- Tighten fasteners as needed before each use
- Check tire pressure before each use
- Grease wheels annually

Do-It-Yourself Accessories





USE 1/2" PLYWOOD





USE STANDARD 2 X 4







USE NOMINAL GRADE C 1 X 3

Craftsman Two Year Limited Warranty

FOR TWO YEARS from the date of purchase, this product is warranted against defects in material and workmanship. With proof of purchase, a defective product will be repaired or replaced at option of seller. This warranty does not cover tires and wheels, which are expendable parts that can wear out from normal use within the warranty period.

This warranty does not cover:

- Repairs necessary because of operator abuse or negligence.
- Equipment used for commercial or rental purposes.
- Paint that is worn or faded due to normal use or exposure.

To arrange for product repair call 1-800-652-2321, or return this product to place of purchase for replacement.

This warranty gives you specific legal rights, and you may also have other rights which may vary from state to state. This warranty applies only while this product is in use in the United States.

Sears Brands Management Corporation, Hoffman Estates, IL 60194

In the space below record the purchase date of your Dump Cart.

Model Number **610-24147**

Purchase Date _____

Keep this Owner's Manual and your receipt in a safe place for future reference.

After the two year warranty period all replacement parts may be ordered by calling ***1-800-652-2321***.

When ordering replacement parts, always give the following information:

- Product **12.5 cu ft POLY SWIVEL DUMP CART**
- Model Number **610-24147**
- Part Number _____
- Part Description _____

Repair Parts



ITEM	PART NO	DESCRIPTION	QTY	ITEM	PART NO	DESCRIPTION	QTY
1	311161	Poly Body	1	17	6000312	Swivel Clevis	1
2	6000404	Undercarriage	1	19	6000310	Front Support	1
3	6001663	Drawbar Assembly (incl 4-18)	1	20	6000463	Spacer	1
5	6000369	Shoulder Bolt	1	21	300002	Axle	1
6	3000720	3/8" USS Flat Washer	1	22	6000382	Spacer	2
7	300061	3/8-16 C-Lock Nut	5	23	300076	1" SAE Flat Washer	4
8	6000324	Bushing	2	24	6000283	Wheel	2
9	6000370	3/8-16 x 3-1/2" Hex Bolt	2	25	3000528	5/16-18 x 1-1/2" Hex Bolt	12
10	300055	3/8-16 x 3" Hex Bolt	1	26	6000419	5/16-18 Flange Lock Nut	12
11	300052	3/8-16 x 3/4" Hex Bolt	1	27	6000612	Spring Loaded Hitch Bracket	1
12	6000305	Foot Pedal	1	28	300084	Hairpin Cotter, 2-5/16"	2
13	6000309	Latch	1	29	6002638	Owners Manual	1
14	300075	1/2" USS Washer	1	30	6001667	Hardware Bolt Bag	1
15	6000368	Spring Washer	1	31	6002856	Decal, Craftsman	2
16	6000325	Latch Spring	2	32	6000810	Kit, 1" Wheel Bushings (set of 4)	1

Notes

CRAFTSMAN®

Product questions or problems?

1-888-331-4569

Customer Care Hot Line

Get answers to questions, troubleshoot problems, order parts, or schedule repair service.

Para respuestas a preguntas o problemas, y ordenar piezas o pedir servicio para la reparación de su equipo.

To help us help you, register your product at www.craftsman.com/registration

Para poderte ayudar mejor, registra tu producto en www.craftsman.com/registration

---

Join the Craftsman Club today!

CRAFTSMAN® CLUB

www.craftsman.com/signup

Receive exclusive member benefits including special pricing and offers, project sharing, expert advice, and SHOP YOUR WAY REWARDS!

Como miembro exclusivo, recibe diversos beneficios como ofertas, precios especiales, proyectos nuevos, consejos de expertos y nuestro programa de puntos SHOP YOUR WAY REWARDS!

® Registered Trademark / ™ Trademark of KCD IP, LLC in the United States, or Sears Brands, LLC in other countries
® Marca Registrada / ™ Marca de Fábrica de KCD IP, LLC en Estados Unidos, o Sears Brands, LLC in otros países